
CAPTADOR PONTE
CHAVE 3 POSIÇÕES
POT. TONE PONTE
PUSH PULL 2 (opcional)
PONTE GND CHASSIS
POT. VOLUME PONTE
POT. TONE BRAÇO
PUSH PULL 1 (opcional)
POT. VOLUME BRAÇO
CAPTADOR BRAÇO
VOLUME BRIDGE
TONE BRIDGE
P1
C1
L1 NECK
SW1
GND NECK BOTH
BRIDGE
GND
RD BL WR GR GND
P2
L2 BRIDGE
PP2
C2
VOLUME NECK
J1
JACK
P3
PP1 PPNECK
PPBRIDGE
REV.0
VP005L01
P4
1 MYAKI (11)99547-6150
TONE NECK